



## RECLINER LEVER INSTALLATION INSTRUCTIONS

1. Unscrew handle (2 phillips head screws) from outside panel of recliner, pull handle out from it's secured position.
2. Turn recliner on it's side (handle facing up) to expose the underside of the armchair.
3. Locate the black cable/lead and follow it to the plastic connection clipped into the black metal recliner mechanism.
4. Unclip the plastic connection and remove metal end piece (shaped like an "s") from the lever attached to the metal mechanism.
5. Take the handle and cable completely out of the recliner.
6. Feed cable through the hole in the side panel of the armchair (where the handle was attached).
7. From the underside, direct the cable to the mechanism and feed the metal end piece into the same hole in the lever (metal piece with 3 holes) where the old one was situated.
8. Clip the plastic connection to the mechanism.
9. Fasten screws into the handle to secure it to the side of the recliner.
10. Test the handle works.